

AMS Lower Motor Mount Installation Instructions

-Remove lower splash shield.

-Remove 3 17mm bolts for the cross member and the bolt that goes through the mount. Remove the cross member.

-Remove 2 14mm bolts that hold mount to cross member.

-If you purchased the mount with the bushing already installed, just reinstall the mount back onto the cross member.

-If you just purchased the bushing, you need to press the old one out. Be sure to press the entire sleeve out of the mount. Press new one in. Center it into mount. Drill a 5/64 hole through the mount hole at the top into the bushing. Insert the supplied self tapping screw. (This is done to ensure that the mount never moves.)

-Lube both sides of the bushings and reinstall the cross member piece and all the items that were previously removed.