



AMS EVO X Cold Air Extension Kit

The goal of AMS is to provide the highest quality, best performing products available. By utilizing research and development, and rigorous testing programs AMS will never compromise the quality or performance of our products. In addition, AMS will only provide the finest customer service offering only parts and advice that are in the best interests of the customer. AMS was built on a foundation of integrity. This is who we are; this is what you can count on.

A vehicle modified by the use of performance parts may not meet the legal requirements for use on public roads. Federal and state laws prohibit the removal, modification, or rendering inoperative of any part or element of design affecting emissions or safety on motor vehicles used for transporting persons or property on public streets or highways. Use or installation of performance parts may adversely affect the drivability and reliability of your vehicle, and may also affect or eliminate your insurance coverage, factory warranty, and/or new OEM part warranty. Performance parts are sold as-is without any warranty of any type. There is no warranty stated or implied due to the stresses placed on your vehicle by performance parts and our inability to monitor their use, tuning, or modification.

These instructions are provided as a guide only as there are many variables that cannot be accounted for concerning your particular vehicle, including but not limited to model year differences, model differences, the presence of non-OEM parts, and modifications that may already be or were previously installed. A basic knowledge of automotive parts and systems is helpful but a better understanding of the parts and systems on your particular vehicle may be required.

If you have any questions or issues at any time during the installation of your AMS product(s) please call us for technical assistance. The AMS tech line can be reached M-F, 9AM-PM Central time at 847-709-0530 for AMS products only.

AMS EVO X Cold Air Extension Kit

Parts Included:

- 3" Silicone Coupler
- 4 x Worm Gear Clamps
- 3" 90 Degree Aluminum Bend
- 3" Custom Silicone Tube
- 3" Aluminum Filter Adaptor
- M8x1.25 Bolt 16m Long
- M8 Flat Washer

1. Start off by removing your front bumper and air filter from your current AMS intake.
2. Install silicone coupler where the filter previously was.
3. Install 90 degree aluminum bend onto the other end of the coupler. You will notice that it is longer on one side of the bend. The long end faces down and the short end is installed into the coupler. Leave the clamp loose.
4. Connect the custom silicone tube to the 90 degree bend. It also has a end that is longer, the long side is on top and connects to the 90 degree bend. Leave the clamps loose.
5. Connect the filter adaptor to the end of the silicone bend, note its orientation in the picture below and bolt it into place using the supplied bolt and washer.
6. Tighten up all hose clamps and install filter onto the adaptor.



